



Parts List for DW331K Type 10

Item Number	Part Number	Description	Qty Required
1	589004-01	ARMATURE	1
2	589006-01	FIELD	1
3	582822-01	SWITCH	1
4	589016-01	BRUSH SET	1
5	583696-01	BRUSH HOLDER	2
6	584090-00	CORD PROTECTOR	1
7	325090-11	CORD SET	1
8	330065-06	SCREW	4
10	821070	CORD CLAMP	1
11	572013-02	LEAD WIRE	1
12	572013-03	LEAD WIRE	1
14	330003-56	BALL BEARING	1
15	330065-07	SCREW	6
16	588997-00	HANDLE ASSY.	1
17	581269-00	GUARD	1
18	581239-01	SCREEN	1
20	324006-00	SCREW	4
21	581577-00	CASTING	1
22	584627-00	PIN	1
23	581418-00	SPRING	1
24	589055-00	ACTUATOR	1
25	590362-00	GEARCASE COVER	1
26	581244-00	GASKET	1
27	330045-09	SCREW	2
30	330065-11	SCREW	2
31	582837-00	BOLT	2
32	586203-00	BLADE CLAMP	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW331K Type 10

Item Number	Part Number	Description	Qty Required
33	582262-00	SEAL	1
34	582263-00	FELT SEAL	1
35	586646-00	SPRING,COMP.	1
36	582259-00	BEARING	1
37	581274-00	RECIP. SHAFT	1
38	582260-00	BEARING CARRIER	1
39	324006-00	SCREW	4
40	490329-00	BEARING	1
43	590243-00	SPACER	1
46	582261-00	CLAMP	1
47	582257-00	DRIVE ROLLER	1
48	571181-00	CLIP	2
49	582829-00	WASHER	2
50	479146-00	SCREW	2
51	330004-02	BEARING,NEEDLE	2
52	479403-00	CRANK KIT	1
53	589012-00	COUNTERWEIGHT	1
55	589014-00	GEAR ASSY.	1
56	581247-00	ACTUATOR	1
57	330019-15	SCREW	2
58	589011-00	GEARCASE ASSY	1
65	581255-00	LEVER	1
66	326467-00	DETENT	2
67	582830-00	BODY	1
68	582831-00	BAFFLE	1
70	589056-00	BRACKET	1
72	330041-29	PIN	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW331K Type 10

Item Number	Part Number	Description	Qty Required
73	584450-00	NOZZLE	1
74	330041-49	PIN	1
76	581257-00	LEVER	1
77	330003-96	BALL BEARING	1
78	584639-00	CLIP, SPRING	1
80	581241-00	HOUSING, MOTOR	1
81	581240-00	BAFFLE, FAN	1
82	930029-00	COVER,BRG	1
84	493248-00	LEVER	1
85	581263-00	SHOE	1
86	493248-00	LEVER	1
87	581266-00	ADAPTOR	1
88	584686-00	PLUNGER	1
89	496996-00	CLAMP PLATE	1
90	582826-00	BOLT	1
91	582828-00	WASHER	1
92	582827-00	BOLT	1
93	581281-00	VACUUM ADAPTOR	1
94	581264-00	SOLE PLATE	1
95	389235-00	SCREW	4
96	581268-00	SOLE PLATE	1
100	402140-00	DEVICE,ANTI.SPL	1
800	870889-03	GREASE	1
816	587464-00	ID LABEL	1
821	586840-06	NAME PLATE	1
856	1004501-00	RIP FENCE	1
856	648210-00	JIG SAW BLADE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW331K Type 10

Item Number	Part Number	Description	Qty Required
856	494873-00	BLADE PACK	1
861	393455-00	KIT BOX	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.